





## INSTRUCTIONS FOR USE

---

**INLIGHT** reflective safety vests are **EN ISO 20471:2013** certified. Special care and instructions are to be followed for their proper usages which are as under,

1. Reflective vest should be worn with its velcro or zip tied up.
2. Best fitted vest is to be worn in respect of size. Loose fitted vests can be harmful.
3. When not in use, it should be hanged properly.
4. If the stitching of the vest is worn out due to wear and tear, it should be replaced with a new one immediately.
5. At any point of time, if the coefficient of retro reflective material is less than 300 cd per lux /m<sup>2</sup>, the reflective vest should be replaced.
6. Special wash care instructions are to be followed which are as under,
  - 6.1. Zip the garment and turn it inside out, then machine wash or hand wash it separately.
  - 6.2. Do not bleach the vest.
  - 6.3. Do not dry clean the vest for long life.
  - 6.4. Tumble dry with low speed or dry in shade preferably.
  - 6.5. Low heat set iron only.
7. Misuses of reflective vest can life threatening. Correct class and type of reflective vest should be used in accordance to the requirement.
8. There are working environments and conditions specified for use of reflective safety vest, limiting its use for concerned class and type.
9. Our reflective safety vests are best for use within 25 normal washing cycles.

For Wash care Instructions

	NO CHLORINE BLEACH
	MACHINE / HAND WASH
	IRON LOW SETTING
	No DRY CLEAN

These instructions will help you keep your reflective safety vest in working condition for long time and will keep you safe.